



FIRE AND DINE DIY OVEN

Installation Instructions

Before You Start – Check How Your Oven Was Delivered

Your oven was supplied in one of two ways. Check which one applies to you – it determines which steps to follow.

Delivery option	What you received	Follow steps
		



Step 3 – Fit the Dome onto the Floor *(Option B only)*

Mix the supplied dome mortar with water to a firm, workable paste.

- Apply a bed of mortar along the outer edge of the floor where the dome will sit
- Carefully lower the dome onto the floor
- Line the dome up with the floor from the back of the oven, squarely with the front of the floor (remember your door will rest on the front of the floor. (There should be 20mm standing out on the front of your door.)
- Press down gently so the dome beds into the mortar

⚠ Do not fill or close any internal expansion gaps with mortar if there is any.

Step 4 – Seal the Dome-to-Floor Joint *(Option B only)*

- Work mortar neatly into the joint all the way around the outside of the oven
- Smooth the joint off so the dome and floor look like one complete unit
- Wipe away any excess mortar before it sets

Step 5 – Grout Around the Base *(Options A and B)*

Mix the “grout around the base” with the bonding liquid until it reaches a normal tile-grout consistency.

- Smooth the grout neatly around the bottom edge
- Blend it so the base and oven look like one complete unit
- If you received a textured finish this steps would apply instead of the grout you will receive the touch up textured coating.

Final Steps – Drying *(Options A and B)*

- **Leave the oven to dry for 7 days before starting the curing procedure**
- Keep the oven as dry as possible during this time – the mortar and grout must set properly
- Cover the oven if rain is expected
- After drying, you may apply touch-up paint or a mosaic finish if desired

☒ **Installation Complete**

Congratulations!!

You have successfully installed your very own pizza oven.

Please wait 7 days before starting the **curing procedure**.

Keep your oven as dry as possible during these 7 days so the mortar and grout can set and the oven dries properly. Once dried, apply touch-up paint or a mosaic border if desired.

Thank you.

Fire and Dine Team

For assistance call/WhatsApp: 074 018 0880 or 083 438 1485
Office: 016 013 0411 | info@fireanddine.co.za | fireanddine.co.za
Springbok Ave, Ardenwold AH, Vanderbijlpark, 1911